

HOZAN C-448-1

取扱説明書

C-448-1 ベアリング



ベアリング

C-448のハンドル部とキャップを反時計方向に回して取り外し、交換してください。交換後、キャップはしっかりと締めてください。



T4962772570593

MADE IN JAPAN

旧タイプのヘッドワン圧入工具 C-438 にも使用できますが、つぎのように工具上部から交換挿入してください。

C-438への取り付け方法

- 1 ハンドル部を軸から取り外します。
- 2 ベアリングを交換します。
ベアリングは内径が小さいリングを下に、玉を両軌道溝ではさむように取り付けます。
- 3 ハンドル部を元通り取りつけます。

内径 大

軌道溝
軌道溝

内径 小



ホーサン株式会社

本社 〒556-0021 大阪市浪速区幸町1-2-12

製品・補修部品はWebサイトでご購入いただけます。

<https://www.hozan.co.jp/>



技術的なお問い合わせ

ホーサン テクニカルホットライン

☎06-6567-3132

E-mail: th@hozan.co.jp

【月曜日から金曜日(祝日を除く)の10:30~12:00、13:00~17:00】

HOZAN INSTRUCTION MANUAL

C-448-1 BEARING

Remove the handle part and the cap of the C-448 screwing counterclockwise, then replace the bearing and secure the cap.

Also use for C-438, old-model of HEAD CUP PRESS, threading from the top of the tool.

Installing onto C-438

- 1 Remove the handle part from the shaft.
- 2 Replace the bearing holding the balls between both the raceways of the two rings, one of which with small inner diameter is located at the bottom and the other with large inner diameter is located at the top.
- 3 Fit the handle part as before.



large inner
diameter

Raceway
Raceway

small inner
diameter



HOZAN CO., LTD.

1-2-12 Saiwaicho, Naniwa-ku, Osaka 556-0021, Japan
https://www.hozan.co.jp/cycle_e/ E-mail: th@hozan.co.jp