

クリップライト

Z-306

CLIP LIGHT





簡単にクリップで固定でき暗い場所での手元照明として使用できます。

Use the clip holder for illuminating your space putting on every places.

照射方向を自由に設定できます。 Turn-able to desired directions.

ご使用方法

はじめに

- 1 本体側面のボタン部分を指で挟みながら電池ホルダーを取り出します。
- 2 電池に挟まれている絶縁シートを取り除きます。
- 3 ロックされるまで、電池ホルダーを本体に挿入します。

電源スイッチをクリック音がするところまで押し込むと、点灯、消灯します。

ご使用上の注意

∕\注意

落としたり衝撃を与えたりしないでください。

電池交換方法

- 1 本体側面のボタン部分を指で挟みながら電池ホルダーを取り出します。
- 電池ホルダーの表示に従って、コイン形リチウム電池 (CR2032×2個)を取り付けます。
- 3 電池ホルダーを確実に本体に挿入します。

お願い ほか

付属の電池は動作確認用につき寿命の保証はありません。

長期間使用しないときは電池を抜いて保管して〈ださい。

Operation

First of all

- 1 Draw the battery pack pinching the pulls at the sides of the body.
- 2 Take away the insulation between the batteries.
- 3 Inset the battery pack into the body until locked.

Push the power switch until click for turn on/off the light.

Precautions

∆Caution

Do not drop or cause impact.

How to exchange batteries

- 1 Draw the battery pack pinching the buttons at the sides of the body.
- 2 Load two CR2032 batteries according to the Indication on the battery pack.
- 3 Put back the battery pack into the body securely.

Note

The factory-loaded batteries are for confirmation of operation only and not warranted on the life.

Store without batteries if not use for a long period.

ホーザン株式会社